



Index No.	Part No.	Description	Qty.	Index No.	Part No.	Description	Qty.
1		Housing	1	8950400148	Spring-Drum Assy CP9940	1	
2		Axle	1	8950400160	Spring-Drum Assy CP9946	1	
3	8950010380	Nut	1	8950400161	Spring-Drum Assy CP9947	1	
4		Cover	1	8950400162	Spring-Drum Assy CP9948	1	
5		Hook	1	8950400163	Spring-Drum Assy CP9949	1	
6		Adjusting Knob	1	8950400164	Spring-Drum Assy CP9950	1	
7		Spring	1	14	8950400103	Guide	1
8		Hook	1	15	8950400004	Wire Complete	1
9	8950400123	Spring	1	16	8950010379	Screw	3
10		Screw	1	17		Spacer	2
11	8950040074	Retaining Ring	1	24	8950400005	Hook	1
12	8950400149	Washer	1	25		Screw for CP9946, 47, 48, 49, 50	1
13	8950400143	Spring-Drum Assy CP9936	1			Clamp	1
	8950400145	Spring-Drum Assy CP9937	1			Wire	1
	8950400146	Spring-Drum Assy CP9938	1	6158727980	Safety Label	1	
	8950400147	Spring-Drum Assy CP9939	1				